



ILLUMINATED RELAXATION BUBBLE LIGHT

AQUASCAPE

CD TOWER



Instruction Manual and Warranty Information

BL-CD

ONE YEAR LIMITED WARRANTY

(Valid in USA only)

HoMedics, Inc., guarantees this product free from defects in material and workmanship for a period of one year from the date of purchase, except as noted below.

To obtain warranty service on your HoMedics product, either hand deliver or mail the unit and your dated sales receipt (as proof of purchase), postpaid, along with check or money order in the amount of \$10.00 payable to HoMedics, Inc. to cover handling.

Upon receipt, HoMedics will repair or replace, as appropriate, your product and return it to you, postpaid. Warranty is solely through HoMedics Service Center. Service of this product by anyone other than HoMedics Service Center voids warrantv.

For more information regarding our product line in the USA, please visit: www.homedics.com

This HoMedics product warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product; or any other conditions whatsoever that are beyond the control of HoMedics. This warranty is effective only if the product is purchased and operated in the USA. A product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications is not covered under warranty. HoMedics shall not be responsible for any type of incidental, consequential or special damages. All implied warranties, including but not limited to those implied warranties of fitness and merchantability, are limited in the total duration of one year from the original purchase date.

Commerce Township, MI 48390 e-mail: cservice@homedics.com

Service Center Dept. 168

3000 Pontiac Trail

Mail To:

HoMedics

© 2001 HoMedics, Inc. and its affiliated companies, all rights reserved. HoMedics $^{\circledR}$ is a registered trademark of HoMedics, Inc. and its affiliated companies. Aquascape $^{\intercal}$ and Body Basics $^{\intercal}$ are trademarks of HoMedics, Inc. and its affiliated companies. All rights reserved.



A Kaleidoscope of Bubbling Light

Thank you for purchasing the HoMedics AquaScape Illuminated Relaxation Bubble Light and CD Tower. Like the entire line of HoMedics products, it is built with high-quality craftsmanship to provide years of dependable service. We hope you find it to be the finest product of its kind.

HoMedics Illuminated Relaxation Bubble Lights can turn any room into a private sanctuary in which to relax both mind and body while also serving to organize your CD collection. It is a great addition to any entertainment center.

Tune out the world and tune into yourself as your thoughts slowly sink into the shimmering, light of our Relaxation Bubble Lights. Indulge your eyes in the kaleidoscope of incandescent bubbles and colorful floating spheres. Let your mind wander and feel your body begin to unwind.

AquaScape CD Tower Features

- Holds up to 50 CDs
- Continuously changing colors illuminate bubbles in shades of red, yellow, green and blue
- 50 colorful spheres included
- Pump is contained in base for an attractive, finished look.
- · Contemporary, geometric design
- Adds sparkling tranquility to any room
- Simple assembly in minutes
- Two Spare halogen bulbs included

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING DANGER To reduce the risk of electric shock:

2

- Always unplug the appliance from the electrical outlet immediately after using and before cleaning.
- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- If the unit is knocked over, unplug immediately.
- Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.

Caution:
Only set the bubble light and bubble light parts on water-proof surfaces.

Do not place in a high-traffic area where it could be bumped or knocked over.

Important Note:
Your AquaScape
bubble light
incorporates a
high-efficiency
air pump to
generate the
powerful bubble
action. The low
level of noise
emitted by this
product is normal and should
be expected.

Caution: Please keep small children away from color spheres to avoid choking.

- To reduce the risk of electric shock, connect only to a 120 volt A/C household outlet. Do not connect to any voltage other than that shown on the pump.
- Do not use flammable liquids.
- Do not use water above 90 degrees Fahrenheit.

WARNING: To reduce the risk of burns, fire, electric shock or injury to persons:

- An appliance should never be left unattended when plugged in.
 Unplug unit from outlet when not in use and before putting on or taking off parts or attachments.
- Close supervision is necessary when this appliance is used by or near children, invalids or disabled persons.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by HoMedics, specifically any attachment not provided with the unit.
- Do not operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or the cord has been dropped into water. Return it to the HoMedics Service Center for examination and repair.
- · Keep cord away from heated surfaces.
- Never drop or insert any object into any opening unless otherwise directed in this instruction manual.
- Do not operate where aerosol spray products are being used or where oxygen is being administered.
- Do not carry this appliance by supply cord or use the cord as a handle.
- To disconnect, remove plug from outlet.
- This appliance is designed for indoor use only. Do not use outdoors.

SAVE THESE INSTRUCTIONS

Caution – Please read all instructions carefully before operating.

- If you have any concerns regarding your health, consult your doctor before using this product.
- Never leave appliance unattended while operating the unit, especially if children are present.
- Never cover unit when it is in operation.

3

- Connect the adapter only to 120 volt A/C household outlet as indicated on the label.
- Always keep the cord away from high temperature and fire.
- Unplug from the power source before cleaning, performing maintenance, and disassembling.

- To get the most efficient bubbling effect, product must be placed on a level and sturdy surface before using, and should not be placed on any type of electrical appliance.
- Operate with distilled water to avoid lime residues. The pump is not equipped to run with salt water (sea water).
- The electrical cord of this product cannot be replaced. If it sustains damage, you must stop using the appliance immediately and return it to the HoMedics Service Center for examination and repair. (See the warranty section for HoMedics address.)
- Disconnect the appliance from power source before putting hands into water.
- If the device has been exposed to a drastic temperature fluctuation, do not plug in the bubble light immediately. The condensation may damage the product. Do not connect to power source until it has returned to room temperature.
- Always disconnect your AquaScape before filling with water, or before opening the base housing.
- Never fill the AquaScape with hot liquids.
- Should you notice any leaks from your AquaScape, unplug it immediately and contact HoMedics Customer Service.
- Keep out of reach of children.

Assembly and Instructions for

Figure 1




Figure 2





Figure 3



Use

- Carefully remove your bubble light from its packaging. Be sure your new light assembly includes (Fig.1):
 - an AC adapter with cord
 - 50 color spheres
 - 2 halogen replacement bulbs
- Your bubble light requires no mechanical assembly. Simply wipe off any dust with a damp cloth and thoroughly rinse out the clear acrylic portion of your light to remove any excess dust. Do not get the base and electrical cord wet.
- 3. Place the bubble light on a level, sturdy surface. Be sure it is not exposed to direct sunlight, heat, moisture, or dust.
- 4. Fill the bubble light to the optimum water level with distilled water being careful not to exceed the maximum fill line (Fig.2). Distilled water will avoid lime residues. NOTE; The optimum water level is marked on the exterior of the bubble light. To avoid algae build-up, regularly add algaecide to the water. This can be purchased at any fish supply store.
- 5. For added color, insert spheres into tubes now, one packet per tube.
- 6. Place the top cover on the unit.
- 7. Plug the end of the electrical cord into the back of the bubble light, and then plug the adapter into a 120 volt household outlet (Fig.3). The bubble light is in operation once plugged into an electrical outlet, and must be unplugged to be turned off. NOTE: This bubble light is designed so that it can run continuously. However, it is not recommended to leave any electrical appliance, such as this one, unattended while it is still running.

Changing the Lightbulb

Your AquaScape Bubble Light is equipped with

Figure 4




Figure 5





Figure 6



10-watt, 12-volt halogen bulbs. Two replacement bulbs are also included, and should be stored until needed.

- 1. Unplug the unit.
- Remove the top cover, then empty unit of all water.
- To remove the base, unscrew outer eight screws on the bottom of the base with a Phillips screwdriver. The pump will remain attached to the base (Fig.4). Slightly lift the cover.
- Using pliers, remove the nut holding the color wheel in place and remove color wheel, revealing the halogen bulb (Fig. 5).

NOTE: Allow the bulb to cool if hot. Do not attempt to replace a hot bulb.

- Carefully pull up and away to disconnect the two springs from the metal frame which holds the bulb in place. Remove the metal frame, and set it aside (Fig.6).
- 6. Carefully remove the old bulb by pulling straight up (Fig. 7).
- 7. Replace with the new bulb.
- 8. Set the metal frame on the bulb, and reattach the two springs to hold the bulb in place.
- 9. Place the color wheel over the bulb, and reattach the nut to hold the wheel in place.
- When reconnecting the pump and base, ensure there are no kinks in the tubing and the electrical cord is not twisted.
- Plug cord into the back of the bubble light and then plug adaptor into a 120 volt household outlet.

NOTE: Use only the type of bulb specified in this instruction manual.

Caution: Except changing the lightbulb, servicing of this bubble light must be performed by authorized HoMedics service personnel only.

Figure 7



Cleaning and Maintenance

• To clean your AquaScape:

Never use solvents or aggressive detergents to clean your bubble light. Use only a soft, damp cloth to wipe the acrylic water chamber and base carefully and remove all residues without scratching the plastic.

To keep water clean:

To avoid algae build-up, regularly add algaecide to the water. This can be purchased at any fish supply store. Also, a humidifier and vaporizer treatment can be added to the water to help it stay clean. Be sure to periodically change the water and clean the product according to the water condition.

Keeping the water at an optimum level:

Add water periodically to maintain an optimum water level. **NOTE:** The optimum water level is marked with a removable sticker.

AquaScape Storage:

Unplug the bubble light from the electrical outlet, empty the water and store in a cool, dry place.

Troubleshooting

If the pump fails to operate, check the following:

Check the household circuit breaker or plug unit into a different outlet to make sure the water pump is getting electrical power.

NOTE: Always disconnect the unit from the electrical outlet before handling the pump.

Maintaining a desired water level:

Check the water level daily in the first week to measure the rate of evaporation. Refill with water as needed.

Weak Air Pressure:

If the air pressure is weak or if there are no bubbles, but the light is operating, open the base and check that the plastic tubing is not kinked or disconnected. If kinked, gently squeeze the tube back in with your fingers. If disconnected, reconnect the tubes and connect the tube to the pump.